

LATCH Manual Update Related to Chapter 7, Page 73

2021 LATCH Manual Updates Page, www.saferidenews.com

Note: If you are updating more than one *LATCH Manual*, see page 2.

Evenflo U.S. 800-233-5921 Canada 937-773-3971	Revolve360 all-in-1	Method cannot be defined as either Swedish or Australian	No; tether only to a vehicle TA.	Tether, which is on the CR's base, must be attached when the CR is in FF or RF harness mode. Detach and properly store tether in booster mode.
--	----------------------------	--	----------------------------------	--

LATCH Manual Update Related to Chapter 7, Page 73

2021 LATCH Manual Updates Page, www.saferidenews.com

Note: If you are updating only one *LATCH Manual*, see page 1.

Evenflo U.S. 800-233-5921 Canada 937-773-3971	Revolve360 all-in-1	Method cannot be defined as either Swedish or Australian	No; tether only to a vehicle TA.	Tether, which is on the CR's base, must be attached when the CR is in FF or RF harness mode. Detach and properly store tether in booster mode.
--	----------------------------	--	----------------------------------	--

Evenflo U.S. 800-233-5921 Canada 937-773-3971	Revolve360 all-in-1	Method cannot be defined as either Swedish or Australian	No; tether only to a vehicle TA.	Tether, which is on the CR's base, must be attached when the CR is in FF or RF harness mode. Detach and properly store tether in booster mode.
--	----------------------------	--	----------------------------------	--

Evenflo U.S. 800-233-5921 Canada 937-773-3971	Revolve360 all-in-1	Method cannot be defined as either Swedish or Australian	No; tether only to a vehicle TA.	Tether, which is on the CR's base, must be attached when the CR is in FF or RF harness mode. Detach and properly store tether in booster mode.
--	----------------------------	--	----------------------------------	--

Evenflo U.S. 800-233-5921 Canada 937-773-3971	Revolve360 all-in-1	Method cannot be defined as either Swedish or Australian	No; tether only to a vehicle TA.	Tether, which is on the CR's base, must be attached when the CR is in FF or RF harness mode. Detach and properly store tether in booster mode.
--	----------------------------	--	----------------------------------	--