2021 LATCH Manual Updates Page, www.saferidenews.com

All Evenflo CRs

Tethers

- Tether use required in some instructions. Evenflo recommends use of tether for all forward-facing installations, whenever possible. It has also made rolling changes to certain model instruction manuals that say a tether must be used when forward facing, and the tether must be used in RF and FF harness modes for all *Revolve360* CRs. Always follow the instructions provided for the particular CR.
- Maximum child weight for tether use: When forward facing (and, for *Revolve360*, rear facing), Evenflo recommends or requires tether use at all allowed CR usage weights. (However, do not use Revolve360's tether in booster mode at any child weight.)
- Tethering rear facing: *Revolve360* requires tether use in both rear-facing and forward-facing harness-use modes. Not allowed with any other Evenflo CR.

CRs Used in Booster Mode

• LATCH use with boosters: For combination and allin-1 CRs, use of the tether and LA attachment is allowed in booster mode as long as the booster's position in the vehicle and/or the resulting seat belt fit over the child are not affected. This permission is retroactive for all Evenflo models in booster mode. If LA attachment/tether are not used, they must be stored per instructions. (Exception: May not use *Revolve360* tether in booster mode; store the tether per instructions.)

Convertible CRs

LA Attachments

- Belt path and converting between RF and FF:
- **Revolve360** does not require reinstallation for converting between rear and forward facing. For all other models, pull pad back from leg area of CR to access RF belt path. To access FF path, it may be necessary to lift center pad and raise head restraint to highest position.
- Storage: Varies by CR model. For most, when installing the CR using a seat belt, route the LA strap through the belt path that does not hold the seat belt before attaching the LA connectors to designated storage points. *Revolve360*: The LA strap is permanently routed under blue belt guides of belt path; a seat belt would be routed *on top* of the blue belt guides. Do not overtighten the LA strap while in storage, as that may interfere with seat belt installation.

Tethers

• Storage: Clip hook to holes/bars on back of CR shell. Roll up excess strap, and secure with a rubber band. Note: The stored tether of *EveryStage* models may be located in between the base and the CR shell; if the CR is reclined, the stored tether may not be visible until the CR is moved into a more upright position. *Revolve360*: Attach the tether hook to the bar provided on the bottom of the base; the tether must be used in both rear-facing and forward-facing harness modes but must be stored (unused) in booster mode.