

Car Seat Recalls/Defects & Safety Notices - Revised 11/6/23

Ensure you are looking at the most recent list! Scan the code (left) using a smartphone camera or app. This printed list includes child restraints manufactured after 1/1/2013 (most recent addition shaded gray). Note: Since most car seats expire in fewer than 10 years from the date of manufacture, some car seats on this list may no longer be covered by the recall notice; rather than be repaired, they should be replaced and properly discarded. Contact the manufacturer for all recall details.

Find this list under Resources at <u>www.saferidenews.com</u>. This recall list format was originally developed by the WA State Safety Restraint Coalition and is currently maintained by Safe Ride News Publications.

4moms

888-614-6667

Infant Seat

4moms.com

Self-installing Car Seat made

7/1/16-10/31/16. **Problem:** Hooks that lock the carrier to the base may stick or fail to attach. Until replaced, double check proper locking into base by pulling up on carrier handle; or install carrier without base. **Call:** 888-614-6667 or visit *4moms.com/recalls*

Angel Guard

(See Merritt Manufacturing)

Aprica (See Graco; all units expired)

Aria Child (See Goodbaby)

Baby Jogger, LLC

800-241-1848

RF-Only Seats

babyjogger.com

- City GO Infant Seat Models BJ64510, BJ64529;
- City GO Infant Car Seat Base Models BJ80400, BJ61500;
- City Mini Stroller System Model BJ72510;
- Vue Lite Stroller System BJ70411, BJ70424, BJ70431

Made 11/3/14 - 4/30/15. **Problem:** Incorrect/missing information on labels/instruction book may decrease correct use of seat increasing risk of injury. **Call:** 800-241-1848.

Note: These units are all expired.

Baby Trend

800-328-7363

Combination Seat

babytrend.com

Hybrid 3-in-1 Combination

Booster (Desert Blue, from Walmart) Model: #FB49E14A 12/21 Made on: 12/6/2021 **Problem:** The LA strap, if frayed, may not meet the strength required by FMVSS 213 and FMVSS 209. Registered owners will automatically receive a replacement LA attachment and instructions. Until received, install CR using a seat belt. If a seat belt *cannot* be used, inspect the original LA strap carefully for fraying or other damage and, if in good condition, use it only until it can be replaced.

Call 800-328-7363 for information or search Recalls and Safety Notices at <u>www.babytrend.com</u>.

Hybrid 3-in-1 LX model FB48417 made 7/14/16 sold only at Wal-Mart & model FB58181 made 7/23/16 sold only at Military Exchanges. Problem: In a crash, center adjuster may detach in harnessed mode if child weighs more than 40 pounds. Call: 800-328-7363 (NOTE: This car seat in harness mode is now expired.)

3-in-One TrendZ Fastback Models FB60070, FB60408 made 10/11-7/13. **Problem:** Buckle may become difficult to unlatch or become stuck in latched position. **Call** 800-328-7363 for new buckle. (NOTE: This car seat in harness mode is now expired.)

Bergeron	(No Recalls)
800-371-2778	adaptivemall.com
Britax 888-427-4829	www.britaxusa.com
000-427-4029	www.biitaxusa.com

RF-Only Seats

B-Safe 35 and B-Safe 35 Elite Recall #1 of 2:

Made 11/1/15 through 5/31/17.

BOB B-Safe 35 (w/stroller system)

- Beginning E9LT3: 4A, 4C, 5X
- EXLT34A.

B-Safe 35 Models

- Beginning E1A: 183F, 185M, 185P, 186R, 203F, 205M, 205P, 206X, 206Z, 207E
- Beginning E9LU: 65V, 66X, 66Z, 67D, 67E. EXA185M
- Beginning S020: 63600, 63700.
- Beginning S03803: 400, 500, 700, 800, 900
- Beginning S04: 144400, 144500, 144600, 145000, 402800, 884200, 884300, 975600,978900
- Beginning S0: 5260200, 6020300, 6020400, 6020500, 6020600, 6020700, 6020800, 6020900, 6147100
- S921800

B-Safe 35 Elite Models

- Beginning E1A2: 15T, 15U, 16P, 21Q, 25C, 25U, 26L
- Beginning E9L: S5,1Q, 6C, 6L, 7F, 7G, 7H
- EXA216L, S923700
- Beginning S0: 1298600, 2063800, 2063900, 2064000, 4281200, 4281300, 4628500, 6018800, 6020000, 6020200

Problem: Center tab on chest clip can break, presenting choking hazard.

Call: 833-474-7016.

Recall #2 of 2:

Made 10/1/14 through 7/1/15 **B-Safe 35** (w/stroller system) models beginning S91 plus: 4300, 4500, 4700, 4900, 5400, 5200 **as well as** S921900 **and** S01635200 **B-Safe 35** Models

• EXLU65M

 Beginning E9L plus: U65M, U65P, U63F, U66R, V15M, V15P, V13F.

B-Safe 35 Elite Models beginning E9LS plus: 55T, 56P, 55U, 66C, 65U.

Problem: Car seat carry handle may crack/fracture while being carried. Do not carry by handle until fixed. Recall does not affect seat when used in vehicle or on stroller. **Call:** 800-683-2045.

Note: These units are now all expired.

Convertible Seats

Advocate 70-G3, Boulevard 70-G3 and Pavilion 70-G3 models begin "E9L" J91A, E91M, J91S, J92E, J93P, J93S, K91A, K31A, K31Q, K32D, K32Z, K33Q, L11A, L11Q, L12D, L12Z, G81A, G83N, G83P, G83X, G83Y, L21A, L23P, L23Y made 6/1/12 - 8/31/12. Problem: Child chewing on HUGS chest pad may bite off small piece, presenting choking hazard. Call: 888-427-4829

Note: These units are now all expired.

ClickTight Convertible models:

Made 8/1/14 - 7/29/15

Advocate ClickTight Models beginning E9LT plus: 86F, 86G, 86A, 86H, 85Q, 85S and beginning E1A plus: 135Q, 015Q, 016A, and 016H.

Boulevard ClickTight models beginning E1A plus: 013Q, 016A, 016H,135Q, LT85Q, and beginning E9LT plus: 85Q, 85S, 86A,

86F, 86G, 86H

Marathon ClickTight models E1A116L, E9LT76P, E9LT71Q, E9LT76N, E9LT76B, E9LT75R, E9LT76L, E1A006B, E1A005R and EXA116L

Problem: Harness adjuster button (red) may remain down in release position and prevent harness from locking. Continue using seat while awaiting repair only if harness button does not stick and harness remains tensioned.

Call: 888-427-4829

Call. 000-427-4	029.
BubbleBui 800-969-6586	n (No Recalls) <u>bubblebum.co/us</u>
Carfoldio	(No Recalls) old.com: out of business
CARES 800-299-6249	(No Recalls; airplane only) <u>kidsflysafe.com</u>
Century	(No Recalls) <u>centurybaby.com</u>
Chicco 877-424-4226	(No Recalls) <u>chiccousa.com</u>
CLEK Inc	

866-656-2462

RF-Only Seats

clekinc.com

Liing Model LG19U1 and

Liingo Model LGO20U1

Problem #1 of 2: On units made prior to 9/15/2020, the canopy support can break under pressure, posing a choking hazard if small pieces are ingested by a child.

Call: 866-656-2462 for a stronger canopy stay; it's safe to use the CR until fixed if canopy is intact.

Problem #2 of 2: On units made prior to 2/22/2021, labels on the seat padding and insert may detach, posing a choking hazard if ingested. Call: 866-656-2462 for replacement pad/insert; it's safe to use the CR until fixed if labels are intact.

Convertible Seats

Flio Model FL15-FO19 and Foonf Model FO12-FO19 Made: prior to 5/21/21. Problem: Pieces of foam cushion from under the padding can be picked loose by the child, posing a choking hazard if ingested.

Call: 866-656-2462 for a plastic insert; monitor child behavior until the repair kit is applied.

Booster Seats

Olli Model OL12U2 made 1/20/20 through 5/10/22 **Ozzi** Model OZ11U2 made 3/1/2020 through 5/10/22.

Problem: Diagram for lap-and-shoulder belt routing not on label.

Call: 866-656-2462 for a new label; refer to owner's manual for belt use instructions until label replaced.

Columbia Medical (See Inspired by Drive)

Columbus Trading-

Partners U.S.A, Inc. (See CYBEX)

Combi USA, Inc.

Email customerservice@combiusa.com

Convertible Seats

Coccoro Model 8220 Made 1/1/09 through 7/31/16. **Problem #1 of 2:** When installed FF and secured with vehicle LAP-ONLY belt, excessive force may be transferred to the car seat. (Note: Recall does not affect rearfacing mode or when the car seat is installed forward facing with a lap/ shoulder belt and lock-off or lower anchors and tether.) **Contact:** Go to *combiusa.com* (select Safety Notifications) **Problem #2 of 2**: Made 1/6/09 -

12/5/12. Harness webbing fails to meet minimum strength requirements. **Email:** customerservice@combiusa.com

Note: Problem #2 units are now all expired.

Zeus 360 made 2/25/09 - 5/24/12, Zeus Turn made 7/15/07 - 3/25/09 Problem: Harness webbing fails to meet minimum strength requirements. Email: customerservice@combiusa.com Note: These units are now all expired.

BabyRide RF-only car seat (no base), model #378099, manufacture dates 5/1/2016—8/31/2019. Problem: The webbing of the 1-inch harness adjuster strap fails to meet the breaking strength requirement of FMVSS 213. Since the segment of this strap that falls *behind* the A-lock adjuster is part of the overall harness,

this strength issue could potentially

cause an infant to be improperly restrained in a crash.

IMPORTANT NOTES: This model is branded by its manufacturer, Nania. During a portion of the recall period, units labeled as Nania BabyRide were imported into the U.S. through a now defunct distributor, Team-Tex America. Therefore, Nania and/or Team-Tex may be prominent on the CR, packaging, and ordering information, whereas Combi. the most recent importer. may not be indicated (but is responsible). BabyRide is a CR with no base that states no minimum weight (allowing use "from birth"), sold exclusively through institutional distributors, so most units in circulation have been provided to caregivers through distribution programs. These programs are advised to check inventory and notify clientele. Contact: Email customerservice@combiusa.com: no remedy announced as of print date.

Compass (See Tomy) Convaid (See Etac) 844-876-6245 etac.us.com Cosco (See Dorel) CYBEX 877-242-5676 cybex-online.com

42-5676 <u>cybex-online.com</u>

RF-Only Seats Aton made 3/29/17-1/4/20. Aton Q made 3/13/17-1/3/20.

Aton M made 3/17/18-11/1/20. Aton 2 made 3/29/17-10/27/20.

Cloud Q made 7/6/17-10/20/20.

Problem: The webbing for the oneinch central harness adjuster strap may fray too easily; when frayed, the webbing fails to meet strength requirements of FMVSS 213. The recall kit has a new harness adjuster strap (with end not folded/sewn) and instructions for replacement. (Owners who previously incurred a cost for replacement due to this problem should call, as well.) **Call:** 877-242-5676

Convertible Seat

Cybex Sirona M models 518000385, 518002153, 518000387, 518002145, 518002149, 518002151, and 519000211, made 11/3/17 through 8/31/18.

Problem: It's possible for a child to pick pieces of foam from the headrest padding, which could be an ingestion/choking hazard. Call: 877-242-5676 to get a manufacturer-provided tape kit with instructions for how to apply it to the lower edge of the headrest's EPS foam. The car seat is safe to use while awaiting the fix, provided caregivers understand that they must monitor children to ensure they do not pick at foam.

Diono 855-242-5676 diono.com

All-in-1 Seats

Radian RXT, Radian R100, Radian R120, Rainier, Olympia, & Pacifica made

11/25/2013-9/25/2017. Problem: The seat may not adequately protect a child when used in harnessed mode & installed forward-facing. Children using seat in booster mode are not affected. Forward-facing children using the harness, who weigh more than 65 pounds (with any installation method) MUST use top tether. For vehicles not equipped with tether anchor. use seat in booster mode. Forward-facing children using the harness who weigh 65 pounds or less whose seat is installed with a laponly belt in vehicles without a tether anchor MUST install repair kit. Call: 855-215-4951.

Booster Seat

Cambria 2 booster model numbers 31200-US-01, 31201-US-01, and 31202-US-01 made 9/5/2020, through 11/30/2020, and used in highback mode. **Problem:** The headrest may crack and possibly separate from the booster during a crash. Diono will provide a replacement seat back. The replacement seat back does not have padding; the instructions will say to transfer the original padding to the replacement seat back and how to attach the seat back to the seat. **Call:** 855-463-4666.

Dorel Juvenile Group

(Cosco, Eddie Bauer, Safety 1st, Maxi-Cosi) 800-544-1108 <u>digusa.com</u>

RF-Only Seats

The base of the following models, all made February 2023 or earlier, with a self-retracting system for the LA attachment. Note: Does not include CRs with similar names that have non-retracting LA attachments.

<u>Maxi-Cosi:</u>

Coral XP (#IC313) made 5/1/20-2/28/23. (Also, see next recall.) Mico XP (#IC336, #IC38) made 9/1/20-2/28/23.

Mico XP Max (#IC337) made

9/1/20-2/28/23.

Mico Luxe+, (#IC370) made 9/1/20-2/28/23.

Any replacement base with selfretracting LA attachment (#IC335) made 5/1/20-2/28/23.

Safety 1st:

onBoard 35 Secure Tech (#IC351) made 5/1/20-2/28/23.

Any replacement base with selfretracting LA attachment (Secure Tech) pre-2/23/23

Also, the recalled base may be included in the following travel systems: Gia XP, Zelia 2 Max, Tayla, Tayla XP, Adorra, Mara XT, and Lila CP (Canada).

Problem: The LA attachment system may not hold the base properly. Owner's will be sent a new base. Until received, install the CR with the base (or baseless) using the vehicle seat belt only.

Call: Contact Dorel at 877-657-9546 or send an email to *RetractableLatchRecall@djgusa.com*

Maxi-Cosi Coral XP #IC313,

all dates. (Also, see prior recall.) **Problem:** The inner carrier cannot be installed in the car without the use of a supplemental device (the outer carrier) and therefore the CR fails to meet FMVSS 213 requirements, including those regarding installation and dynamic performance. Until a refund or replacement has been issued, the CR's inner carrier may be installed while properly attached to the outer carrier, per all instructions. **Call:** 877-657-9546 or email CoralXPRecall@djgusa.com.

Convertible Seats

Maxi-Cosi Pria 70, Pria 85 and Pria 85 Max,

Made Jan. 1, 2019-Sept. 8, 2021 Problem: The car seat allows more forward head movement than allowed by FMVSS 213 when used by a child weighing more than 65 pounds and installed forward-facing using a lap-only belt and no tether. (CRs properly used in rear-facing mode are not affected.) The recall fix from Dorel is new instructions and labeling that limit use of the CR to a maximum child size of 65 pounds or 49 inches for any forward-facing installation. Owners using or intending to use the CR for a child over 65 pounds may request a free Maxi-Cosi Rodi Sport booster. Until fixed. follow these new instructions. Always attach the tether when used forward-facing, whenever possible. Call: 877-657-9546 or email pria85recall@djgusa.com.

Booster Seat

Babideal Model "Storm," #BC901BPXL, made 2/28/19 and sold at Family Dollar stores. Problem: Some required safety labels are missing, and some present labels are for non-vehicle boosters only (wrongly indicating the booster should not be used in vehicles). Call: 877-657-9546 to get a new fabric cover with appropriate labels.

Etac (incl. Convaid, R82)

844-876-6245 etac.us.com **R82 Quokka** made May 2019. **Problem**: A non-recall, consumer advisory: Some units, upon unboxing, have been found to have a broken RF belt guide. **Call**: Consumers with this problem should call 844-876-6245 to order a free fix kit with instructions.

Evenflo

800-233-5921

RF-Only Seats

evenflo.com

Embrace35 made 12/1/11-5/31/13. Models:

- 30711365,
- Beginning 31511: 040, 323, 400, 398
- 3151953, 31521138, 46811205, 46811237
- Beginning 48111: 200, 215, 215A, 218, 234, 235, 235A, 11462,
 Beginning 484: 11391, 11391D.
- Beginning 484, 11391, 113912 11392, 11504, 11504d
 Beginning 52: 0112074, 02104
- Beginning 52: 911307A, 921040,
- Beginning 55: 311138, 311238, 311292

Problem: Harness buckle may become stuck in latched position making it difficult to remove child. **Go to:** <u>buckle.evenflo.com</u>

Note: These units are now all expired.

Convertible Seats

Momentum 65 (LX and DLX) Models beginning "385" made 3/4/13-8/26/13.

Sure Ride DLX Models beginning with "371" made 6/20/12-10/17/13. Titan 65 Models beginning "371" made 6/20/12-10/17/13. Problem: Harness buckle may become stuck in latched position making it difficult to remove child. For new buckle Call: 800-490-7591. (Note: These units are now all expired.)

Titan 65, made 5/20/22: An issued recall applied to only one unit, which had missing labels. The CR was returned to Evenflo and destroyed. No other CRs in the field are expected to have this problem.

Combination Seats

Chase, Chase LX & Chase Select Models beginning "306" made 8/23/11-3/3/14 Chase LX and DLX Models

beginning "329" made 8/23/11-3/3/14.

Secure Kid (LX, DLX, 100, 300, and 400 models) beginning "308" made 12/13/11-3/3/14. Maestro and Maestro

Performance models beginning "310" made 8/22/11-10/17/13 have buckle recall (below) AND **Maestro** numbers made 11/24/09-4/9/10 beginning "310" also have problem #2. **Problem#1 of 2:** Harness buckle may become stuck in latched position making it difficult to remove child.

Call: 800-490-7591

Note: These units are now all expired. Problem #2 of 2: In a crash, crack may form at front of seat causing child to not be properly restrained. Call: 800-233-5921 Note: These units are now all expired.

Evolve # 34411700 and 344117421 Made before 2/9/16. (Affects harness mode only.) **Problem:** Child may reach button and loosen harness. If child loosens harness stop using seat until remedy is installed. **Call:** 800-233-5921.

Transitions #34411686, 34411695, and 34411029 Made 12/18/14-1/29/16. (Affects

harness mode only.) **Problem:** Child may reach button and loosen harness. If child loosens harness stop using seat until remedy is installed.

Call: 800-233-5921.

All-in-1 Seats

Symphony 65, 65E3 (LX, DLX) Models beginning "345" or "346" Made 10/2/12-8/26/13. Problem#1 of 2: Harness buckle may become stuck in latched position making it difficult to remove child.

Call: 800-490-7591 Problem #2 of 2: In a crash, crack may form at front of seat causing child to not be properly restrained. Call: 800-233-5921

Note: These units are now all expired.

E-Z-On Products (No Recalls) 800-323-6598 ezonpro.com

Goodbaby USA

(See Evenflo and Cybex)

Graco 800-345-4109 <u>gr</u>

45-4109 <u>gracobaby.com</u> RF-Only Seats

Models:

SnugRide & SnugRide Classic Connect made 3/1/11-5/31/13 and SnugRide 30 & SnugRide Classic Connect 30 made 7/1/10-1/31/13 and

SnugRide 35 & SnugRide Classic Connect 35 made 5/1/11-1/31/13 and

SnugRide Click Connect 40 made 6/1/12 - 12 /31/12 and Aprica A30 made 7/1/11-4/30/12

Problem: Some buckles become stuck in latched position. Safety of buckle is NOT affected.

Call: 877-766-7470.

Note: These units are now all expired.

Convertible Seats

Classic Ride 50 made 10/1/11-9/30/13.

Cozy Cline, Toddler Safe Seat-Step 2 made 1/1/06 - 4/30/10. My Ride 70 made 5/1/12-7/31/13. My Size 70, Size4Me 70, Headwise 70, Headwise 70 with Safety Surround made 1/1/12-

7/31/13 and 8/3/13. **Ready Ride 70** made10/01/10 -9/30/13.

Smart Seat, Smart Seat with Safety Surround made 12/1/10-9/30/13 and 10/9/13, 12/25/13, 1/10/14

Problem: Harness buckles can become stuck in latched position. Effectiveness of buckle to restrain child is NOT affected. Call: 877-766-7470.

Note: These units are now all expired.

Classic Ride model #1812930 made 3/1/14-2/28/15. **Problem:** Label missing information on instruction book location.

Call: 800-345-4109.

Note: These units are now all expired.

Comfort Sport models 1794333, 1813040 made 3/1/14-2/28/15. Problem Label missing information on instruction book location. Call: 800-345-4109. Note: These units are now all expired.

Extend2Fit model 1954477 made 11/27/15-1/20/16. **Problem:** Recline label affixed to

wrong location may result in infant too upright or toddler too reclined. To confirm unit is affected by recall, also check the recline labels (including the one identifying recline positions 1-6); on each side of seat, they should all be one language (English one side, Spanish the other. If they are not in same language, the unit is subject to this recall.

Call: 800-345-4109

My Ride 65, My Ride 65 with Safety Surround made

4/1/09-7/31/13 and 9/30/13.

- 1908152 made 7/23/14 7/27/14
- 1813074 made 6/20/14 7/27/14
- 1872691 made 5/16/14 8/1/14
 1853478 made 7/11/14 7/27/14
- 183347811ade7/11/14=7/27/14
 1871689 made 7/5/14 -7 /24/14
- 1877535 made 5/26/14 7/27/14
- 1813015 made 7/3/14 7/24/14
- 1794334 made 5/20/14 -7 /15/14

Problem #1: Some buckles become stuck in latched position. Safety of buckle is NOT affected.

Call: 877-766-7470

Note: These units are now all expired. Problem #2: An additional problem for the models listed above and model #1908152 (5/20/14-7/15/14) affects **My Ride 65 only.** If the fabric tag on the harness says "2014/06," the harness webbing does

not meet breaking strength and must be replaced. **Call:** 800-345-4109

Note: These units are now all expired.

Ready Ride Models 1924519, 1923520 made 3/1/14-2/28/15. Problem: Label does not show instructtion book location. (Also see buckle recall earlier on this list.)

Call: 800-345-4109

Note: These units are now all expired.

All-in-1 Seats

Milestone Models 1910130, 1923980, 1926538, 1926539 made 7/9/15-10/9/15. Problem: Labels do not have required wording about how to install seat with LATCH or seat belt per FMVSS 213. Recall does not affect safety performance. Call: 800-345-4109 for new label.

Combination Seats

Argos 70 & Argos 70 Elite made 5/1/11-7/31/13.

Nautilus, Nautilus Elite, Nautilus Plus, 10/1/07-7/31/13 and 8/19/13. Problem: Some buckles become stuck in latched position. Safety of buckle is NOT affected. Call: 877-766-7470.

Booster Seats Turbo Booster Models:

- 1963973 made 3/8/16-4/2/16
- 1963974 made12/22/15-3/30/16
- 1963975 made 12/22/15-3/17/16
- 1963976 made 2/17/16-3/24/16
- 1967886 made 1/13/16-4/5/16
- 1975173 made 3/29/16

Problem: Owner's manual omits instruction to prevent seat from becoming projectile by buckling it when not in use. Seat is still effective to restrain child. Call: 800-345-4109.

Harmony

877-306-1001 harmonyjuvenile.com Big Boost Deluxe made 11/1/15-6/24/17. Problem: In a crash, seat belt may cause excessive force on child's chest increasing risk of injury. Call: 877-306-1001.

Hauck/iCoo (No Recalls) hiccapop (No Recalls) 833-442-2266 hiccapop.com IMMI (See Safe Guard) 317-896-6612 imminet.com InspiredByDrive (No Recalls) Formerly Columbia Medical

800-454-6612 inspiredbydrive.com **JD E-Commerce America**

Limited

Marainbow (made any date, also sold under Joybuy Express) AS WELL AS "materially similar products that may suffer from the noted defects." (Find an image that's representative of affected products and a list of product names, including Portable Infant Safe Seat, at

www.saferidenews.com/unsafeproducts.)

Problem: The device does not comply with FMVSS 213 in several ways. Its design prohibits it from being installed properly, and installation labels display incorrect instructions. It may also lack an owner's manual and/or recall registration card.

Call: 302-426-4543 for a refund. Consumer will be required to prove that the product has been destroyed by sending images to overseasservice@jd.com.

Owners may also contact NHTSA at 888-327-4236 (reference NHTSA Campaigns #22C-007 and #22C-008). Editor's Note: Due to the integral nature of some of the defects, as well as the seriousness of the risk, DO NOT USE this product. It should be replaced with a 213compliant CR that's suitable for the child.

Joybuy Express (See J.D. E-Commerce America Limited,

the recall listed immediately prior.)

Kiddy (No U.S. website or phone) World Plus Combination Seat model 51-100WP made 2/1/12-10/5/13. Problem: Buckle tongue on shield may not fully engage leaving child unrestrained. Affects seat only when used with shield (not as booster: use this seat as booster onlv). Call: 855-925-4339 (Note: SRN has found this number to be no longer in service.)

Kids Embrace (No Recalls)

866-947-3287

kidsembrace.com

Kids II (now Kids2)	
(aka Ingenuity)	(No Recalls)
770-551-0442	kids2.com
Learning Curve	
Lilly Gold	(See Triple Play)

Maxi-Cosi (See Dorel) Merritt Manufacturing 317-409-0148 eztether.com

Car Bed

Angel Ride car beds made 8/8/19-10/24/19. Problem: Harness may not be sewn correctly at the buckle attachment point Call: 317-409-0148 for a harness replacement kit.

Mia Moda (No 866-642-6632	current recalls) <u>dreamonme.com</u>
Mifold	(See Carfoldio)
Nania (See BabyRide under Combi)	
Nuna 855-686-2872	(No Recalls) nunababy.com
Orbit Baby	orbitbaby.com
RF-Only Seats	

Orbit Baby Car Seat Bases G2 Bases model ORB822000 with Batch #A0840, A0860 or A0880 made 3/20/13-7/20/13.

Problem: The base's StrongArm knob may detach or spin without tightening base. Note: These units are now all expired.

Peg Pérego	(No Recalls)
800-671-1701	pegperego.com
Phil&Teds	(No Recalls)

Porsche (Contact Britax)

Portable Child/Infant Seat (See J.D. E-Commerce America Limited)

R82	(See Etac)
844-876-6245	etac.us.com

Recaro

888-973-2276 us.recaro-cs.com

Convertible Seats

ProRide all models beginning with 332.01 made 4/9/10-6/9/15. Performance Ride all models beginning 33301 made 1/15/13-6/9/15. **Problem:** Tether may detach from car seat during crash increasing risk of

injury to child or other occupants. Call: 866-628-4750 Note: These units are now all expired.

Safe Traffic System (No Recalls) 847-233-0365 safetrafficsystem.com

047-233-0303 <u>30</u>	ictianiesystem.com
SafeGuard	(No Recalls)
800-586-7839	<u>safeguardseat.com</u>

Safeline Kids	(See Tripleplay)
Safety 1st	(See Dorel)

Sentry Baby Products (No Recalls) OOB; contact info no longer available.

Simple Parenting (No Recalls) 844-477-9539 www.doona.com/en-US

Snug Seat (See Etac)

Snuali OOB; Contact Evenflo for information.

All-in-One Seats

Snugli All-in-One models beginning "346" made 10/2/12 -8/26/13. Problem: Harness buckle

be difficult to release and could cause risk to child in an emergency. **Note:** These units are now all expired.

Combination Seats

Snugli Booster models beginning

Problem: Harness buckle may be difficult to release and could cause risk to child in an emergency. Note: These units are now all expired.		
Summer Infant (No Recalls)		
800-268-6237	summerinfant.com	
Team-Tex America (See Combi BabyRide)		
Thomashilfen	(No Recalls)	
866-870-2122	thomashilfen.com	
Tomy International (No Recalls) 800-704-8697		
Triple Play 646-484-8112	(No current recalls) lillygold.com	
Uppababy	(No Recalls)	
781-413-3000	uppababy.com	
Urbini	(See Goodbaby)	
WAYB 888-924-9292	wayb.com	

"308" made 12/13/11 - 3/3/14.

Forward-Facing Seat

Pico travel car seat Made 2/1/19 through 8/23/19 Model number ending in -001. Problem: Aluminum tubular frame on headrest can potentially detach from seat, leading to an increased risk of injury in a crash.

Call: 888-924-9292. Go to www.wayb.com/repair for instructions to ship product for repair.